

Procare Touch Computers 12" and 15" models from Posiflex

How to Install the Side Mount Fingerprint Reader and Card Swipe

SIDE MOUNT UPGRADE KIT (OPTION)



Remove the 2 screws circled in the left picture to remove the cover for side mount upgrade kit. Take out the cable inside this cover and connect it to the white connector inside the side mount upgrade kit like SD-680 as arrowed in the right picture. Gently arrange the excessive length of this cable back in the hole and screw-fit it back to



the position originally occupied by the cover. Please reserve the cover if there is chance to have the side mount kit removed in the future.



Before adding side mount



After adding side mount